

| C) Fasten slide brackets (item 3) to outer section of slide using 8-32 hardware. Do |
|---|
| not tighten or adjust. See step D. |

- D) Adjust combination rails in enclosure to suit the distance between brackets or if combination rails are at set distance, slide brackets (item 3) on outer section of slide assembly can be adjusted. To adjust loosen 8-32 screws and nuts on outer slide, adjust bracket location and retighten screws.
- E) Mount outer slide and bracket (item 2) to combination rails at desired location vertically. Secure using 10-32 screws (item 5) thru slide brackets into tapped holes on rails both front and rear. Check that slides are at even height both sides. Install shelf back into mating slides and push back into closed position.
- F) Assemble U handle kit (item 7) with hardware provided.



visit our website @ www.hammondmfg.com

| PARTS LIST | | | |
|------------|---|-----|--|
| ITEM No. | DESCRIPTION | QTY | |
| 1 | SERVER SHELF | 1 | |
| 2 | BALL BEARING SLIDE | 2 | |
| 3 | SLIDE BRACKET | 4 | |
| 4 | 10-32 SCREW | 8 | |
| 5 | 8-32 SCREW | 12 | |
| 6 | 8-32 KEP NUT | 12 | |
| 7 | U HANDLE KIT | 1 | |
| TOOL BO | DX #2 Phillips Tape Screw Driver Measure | | |