



ASSEMBLY INSTRUCTIONS:

A) Place spring nuts (item 3) in C channel at desired location.

B) Loosly attach mounting clamps (item 1) to spring nuts (item 3) using 1/4-20 screws (item 2).

B) Hook one mounting clamp onto the power bar and tighten, then align and hook second mounting clamp on the power bar and tighten.

PARTS LIST		
ITEM No.	DESCRIPTION	QTY
1	MOUNTING CLAMP	2
2	1/4-20 SCREW	2
3	SPRING NUT	2

TOOL BOX

